



Shown above is the "SB2" switchbank which is used to select the local address of the automation.

The numbers above the switchbank indicate the binary representation of the corresponding switch.

Select in binary the value of the of the auditorium desired.

Shown is a representation of address #10 in binary. Select the value by turning on the switches and adding up the binary numbers represented by the switches.

$2 + 8 = 10$ (Auditorium #10)

USE "SB2" TO SET LOCAL AUTOMATION ADDRESS.

IMPORTANT NOTE! WHILE SETTING UP SYSTEM, SET ALL DIP SWITCHES OFF SO THAT THERE ARE NO DUPLICATE ADDRESSES ON THE BUSS. SET ADDRESSES ONE AT A TIME AND CHECK STATUS PANELS AS SETTING THE ADDRESSES. DUPLICATE ADDRESSES WILL CAUSE IRRATIC BEHAVIOR.

BIG SKY INDUSTRIES INC.		
1475 PARK AVE. ALPHA N.J. 08865		
Title A-2000 E address switch settings		
Size A	Document Number REV-E base address settings.sch	Rev -
Date: Wednesday, March 31, 2004	Sheet	1 of 1